



QIG: Management & Control Software

Net-Vision HNC700PT Remote-Motion CCD Network Camera

Start Monitoring

1. Install the program. (NOTE: This application only supports Pentium III or above.)
2. Execute the “Monitor” program via the following path: “Startup Menu\Program Files\16-CH Smart VS-IP Recorder\”. You will be prompted to enter the root password.
3. Use “**root**” as the user name and the password to login.
4. Click “Configurations” on the right most button of the toolbar. In the popup menu, select “Global Settings”. Change the directories if necessary.
5. Select “Camera Configurations” from the “Configurations” menu. Then, the configuration dialog will appear.
6. Click the “Insert” button to bring up the insert channel dialog.
7. Fill the “Address” field with the correct IP address or domain name of your Network Camera (IP), and click “OK” to add it to the camera list. Type in the password of the network camera when the password dialog prompts (if any).
8. If there are no errors/problems, a network camera will be added to you camera list.
9. Press the “Save” button to save the configurations. The camera will be added to each different type of layout (1, 4, 6, 9, 13 and 16 channel settings).
10. You will be able to view the live video in the viewing area. (Note: If you have dragged and dropped the camera for a certain layout, the newly added channel will not be added to the layout. Select the channel ID (for example, channel “1”) from the “Channel” selection area in the upper-left corner. Then drag and drop it into the “view” area on the right side.

Start Recording

1. You must run steps 1-9 from the “Start Monitoring” section above before proceeding.
2. Select “1” from the “Channel” selection area, and press the “Record” button. Then, the program will start recording for Channel 1.
3. After recording data for a desired period, press the “Stop Recording” button to stop recording. The data will be recorded in the directory that you specified in “Global Settings”. (It is recommended that you perform a test recording for a short period of time to test the new settings, before making any important recordings.)

Start Playback

1. You must run steps 1-3 from the “Start Recording” section above before proceeding.
2. Execute the “Playback” program via the following path: “Startup Menu\Program Files\16-CH Smart VS-IP Recorder\”.
3. Enter the root password in the authentication dialog and click the “Ok” button. (Note: If you have already passed the authentication and have not logged out yet, you will not need to be authenticated again.)



QIG: Management & Control Software

Net-Vision HNC700PT Remote-Motion CCD Network Camera

4. Click the “Settings” button in the “System Control” toolbox.
5. Change the directories and modulation mode, if necessary, in the settings dialog.
6. Click the “Ok” button to save these new settings.
7. You will see the recorded video in the display area.